


Artikelnummer: 50.CBS4.0



Cutlery container set



Product specifications

External dimensions (L x W x H)
220 x 220 x 140 mm

Color	Grey
Material	PP
Bottom	Fine mesh
Sidewalls	Fine mesh

Properties

The cutlery drainer is suitable for washing cutlery upright

Comprises four cutlery drainers 50.CBS.0 linked together with a holder

Description

Plastic cutlery holder set (220 x 220 x H 140 mm) with a fine mesh perforation. This prevents the cutlery from protruding through the openings. Consists of 4 cutlery holders, which are linked together by a holder. The cutlery is washed standing in the holders. Cutlery holders can also be used separately. Ideal for use in combination with our universal baskets. Our cutlery baskets and holders are finely meshed to prevent cutlery from falling through, and the open design ensures a perfect rinsing result.



Alternatieve artikelen

