


Article number: 50.CBS4.0



# Cutlery container set



## Product specifications Properties

Uitwendig (LxBxH) 220 x 220 x 140 mm

Sidewalls Fine mesh

Material PP

Article number 50.CBS4.0

Color Grey

Bottom Fine mesh

The cutlery drainer is suitable for washing cutlery upright

Comprises four cutlery drainers 50.CBS.0 linked together with a holder

## Description

Plastic cutlery holder set (220 x 220 x H 140 mm) with a fine mesh perforation. This prevents the cutlery from protruding through the openings. Consists of 4 cutlery holders, which are linked together by a holder. The cutlery is washed standing in the holders. Cutlery holders can also be used separately. Ideal for use in combination with our universal baskets. Our cutlery baskets and holders are finely meshed to prevent cutlery from falling through, and the open design ensures a perfect rinsing result.



## Alternatieve artikelen

